

PRELUDE

— ENGINEERING LLC —

PRELUDE-ENGINEERING.COM

87-90 Legend Coupe 6.5" Front Speaker Buckets



Remove the interior door panel, the procedure is in the factory service manual.

Remove the speaker and factory bucket.

The factory bucket has a metal bracket attached to it. Remove it and install it on the new bucket:



The new bucket comes with a flexible gasket, install it on the bucket now. Alternatively if the factory foam gasket is still in good condition you may be able to transfer it:



Now install the new bucket using the original screws.

Install the 6.5" speaker in the bucket. Some aftermarket speakers may come with screws that are too long. In this case use the shorter screws that were supplied with the new buckets.