

PRELUDE

— ENGINEERING LLC —

PRELUDE-ENGINEERING.COM

87-90 Legend Coupe Front Bumper Plugs Installation Instructions



If you still have threads present behind the bumper cover use a screwdriver to push them further in. This will make room for the tip of the bumper plug to pop in. If you don't do this then the plug may not be able to fully seat:





The plugs are shaped to match the curve of the front bumper and must be installed on the correct side.

On the back of each plug are markings “R” or “L”.

Please keep in mind these side are marked just like all the other parts on the car. Don't get the right and left mixed up because you are looking at the front of the bumper.

This is where you will install the plugs based on the markings.



Place the plugs part way in and observe that they look correct before proceeding:



Push on the center of the plugs until they pop into place:



Install complete:

