

PRELUDE

— ENGINEERING LLC —

PRELUDE-ENGINEERING.COM

87-90 Legend Coupe Rear View Mirror Vibration Damper



NOTE: You can install the vibration damper without removing the mirror. It is only shown removed in these instructions for visual purposes.

Put the lower vibration damper onto the mirror stem and push it forward, rotating side to side a bit until it slips around either side of the ball joint:



Install the upper vibration damper around the previously installed lower damper. You first will put it on angled to the side a bit:



Once it is on and roughly in place push it to the side to rotate it. It should then be sitting vertical and braced against the windshield.

It will be under a bit of tension and may bulge slightly.

Don't pull down hard on the mirror stem when doing this as it's possible to pop the mirror off of its mount:



Adjust the upper damper as needed so that it is wrapped around the lower damper well, please refer to the following images:





The final step is to adjust the rear view mirror position as you like and while holding it in place push both vibration dampers forward so that everything is snug.