

PRELUDE

— ENGINEERING LLC —

PRELUDE-ENGINEERING.COM



88-91 Honda Prelude 6.5" Front Speaker Buckets
Installation Instructions

Remove the interior door panel. Check the service manual for the procedure:
<https://www.preludepower.com/threads/88-91-prelude-factory-service-manuals-and-electrical-troubleshooting-manuals-pdf.466494/>

Remove the 4 screws holding on the factory bucket and keep them.



Place the Prelude Engineering bucket in place with the included gasket and secure it with the original screws:



Now you can install your 6.5" speaker. There are multiple sets of slotted holes for both 4-screw and 3-screw speakers. This allows you to "clock" the speaker a few ways, depending on what will be best for your install:



Your aftermarket speakers may come with screws that are too long. We have included 8 shorter screws you can use if that is the case:

