



88-91 Prelude USDM Rear View Mirror Buzzer Delete



Remove the 3 screws securing the rear view mirror and warning/buzzer:



Unplug the buzzer and tuck the wiring above the headliner:



The delete panel holes have a slight interference, pop it onto the rear view mirror like so. The holes are slotted so you can adjust it a little bit to get the best fit to the headliner:



Reinstall the rear view mirror with the delete panel:



Install the rear view mirror cap by pushing it straight up, it will pop into place:



If you ever need to remove the rear view mirror cap pry *slightly* outward on both front corners and pull straight down.

WARNING: Only flex the front corners very slightly (use little force)! You should mostly be pulling down hard to pop it off. If you pull on the corners too hard the cap is likely to break!

